

A-Tach # 20067



Designed for: Toyota Tundra 2022 - 20__

A-Tach

Mobile Device Mounts

NOTICE: A-Tach Mounts will not be responsible for any damage to the vehicle due to the installation and/or use of the product. The product has been tested to fit securely to the listed vehicles. Instructions are provided for your convenience. You are responsible for the use of the product and to determine if you have the skill to attach the product without causing damage to your vehicle or the product.

Read all instructions and view the photos before attaching this product.

WARNING: Please hold the vehicle mount and holster over the place where the solution attaches to the dash BEFORE securely attaching it to the vehicle. This will insure you like the fit and location of the solution.



(1) The holster comes with a two part securing strap for the hand gun. Place your hand gun into the holster. Then snap the two parts of the strap together and place the strap in a position that will secure the hand gun into the holster.



(2) Slide the hooked parts of the Velcro on the strap into the slots on the sides of the holster. Using the included blue card stock will help. The strap is adjustable by the distance the straps are inserted into the slots. Be sure to align the hooked parts of the Velcro with the mesh parts to create a secure connection.



(3) Consider if you want the holster for right hand use or left hand use. Gently open the lower holster hook and insert the lower edge of the holster under the hook.



(4) Attach the side of the holster to the mount by inserting the steel clip arm on the mount through the clip slot on the side of the holster.

See additional instructions on the back side.



(5) Inspect the area the SAMS will attach to ensure it will not be an obstruction. Clean the area where the mount will attach. The top of the mount will attach onto the top of the left side of the center console panel illustrated with the arrow above.



(6) The bottom of the mount will attach onto the bottom of the left center console side panel illustrated with the arrow above.



(7) Remove the covering from the tape. Press the top edge of the mount onto the front left top edge of the left center console panel.



(8) Press down on the left side of the mount. At the same time



(9) Press in and hook the lower "J" shaped edge of the mount onto the bottom of the left console side panel.



(10) The SAMS attached. The tape will not leave any residue if the mount is removed.