

## A-Tach # 50015



ST-1

# A-Tach

Mobile Device Mounts

**NOTICE:** A-Tach Mounts will not be responsible for any damage to the vehicle due to the installation and/or use of the product. The product has been tested to fit securely to the listed vehicles. Instructions are provided for your convenience. You are responsible for the use of the product and to determine if you have the skill to attach the product without causing damage to your vehicle or the product.

Read all instructions and view the photos before attaching this product.

**Designed for:** Ram Trucks 2019 - 20\_\_

For best results, hold the vehicle mount over the place where the mount attaches to the dash **BEFORE** attaching the device holder to the vehicle mount to ensure a proper fit with the location. Most often the mount will appear to be a little too big or small for the intended location. The vehicle mount must be installed **BEFORE** a device holder is screwed onto the vehicle mount.

**Once screwed together the products are considered used and non-refundable.**

The vehicle mount is not designed to be attached and taken off the vehicle repeatedly or on a regular basis. Once it is attached, it should remain attached until you would like to permanently remove it.

**WARNING: AVOID extreme heat conditions. It can damage the device and the mount.**



(1) Clean the area where the mount will attach. Insert the included seam tool into the seam between the padded part of the dash and the left frame around the center dash area.



(2) The left edge of the mount will go into the seam between the padded part of the dash and the frame around the speedometer panel. See where the finger is pointing in the photo.



(3) Remove the tape coverings. Insert the thin left edge of the mount (The left side is the longer of the two sides.) into the seam between the padded part of the dash and the frame around the speedometer panel.



(4) Flex the right side of the mount to the left and insert the right edge of the mount into the seam next to the seam tool. Remove the seam tool. **Note:** This is a truck mount and will attach firmly to the dash. It will take some pressure to attach.

## Warranty and Returns

### **A-Tach Mounts Limited Warranty**

A-Tach warrants the product to be free of all defects in materials and workmanship for a period of six (6) months from the date of purchase. This warranty extends to the original buyer. Damaged products caused by anything outside of shipping damage are not covered by this warranty.

Within the period of this warranty, A-Tach has the option to repair or replace the item or refund the purchase price. Any replacement parts will be done on an exchange basis. All repairs and service must be done by A-Tach. Product must be delivered to A-Tach during the warranty time along with proof of purchase price and date. The shipping and packaging costs will be the buyer's responsibility. Labor costs and parts to repair will be A-Tach Mounts responsibility.

A-Tach Mounts will not be responsible for any damage to the vehicle or product due to the installation and/or use of the product. A-Tach is not responsible for damages caused by extreme heat conditions. Any above exclusion may not apply in states that do not allow the exclusion or limitation. This warranty gives you specific legal rights. You also may have other rights which vary from state to state.

### **Returns**

Before any product may be returned, A-Tach must give prior approval. An RMA# (Return Merchandise Authorization Number) needs to be given to the buyer to return a product. All returns must be within (30) days of the invoice date and include proof of purchase. Any returned product must be undamaged and in like new condition. Returned product must be scratch free with no additional holes or screw marks on the product.

A-Tach reserves the right to withhold any refund if the product is believed to be damaged. A return must include a copy of the original order or invoice. All parts and components that were shipped with the original product must be included with the returned product.

### **Contact Information:**

A-Tach Mounts  
Clarkston, WA 99403  
cs@attachmounts.com