

A-Tach # 50172



Designed for: Cadillac Escalade (2001 - 2006) | Chevrolet Avalanche (1999- 2006) | Chevrolet Silverado (1999- 2006) | Chevrolet Silverado Classic (2007) | Chevrolet Suburban (2000-2006) | Chevrolet Tahoe (2000- 2006) | GMC Sierra (1999- 2006) | GMC Sierra Classic (2007) | GMC Yukon (2000- 2006)

ST-1

A-Tach
Mounts

A-Tach solutions consist of two separated parts that are brought together to create a secure mounting solution. The first part is the vehicle mount and the second part is the device holder. The vehicle mount is not designed to be attached and taken off the vehicle repeatedly or on a regular basis. Once it is attached, it should remain attached until you would like to permanently remove it.

Attention: Read all instructions and review the images before attaching this product.

Online instruction can be found on the product page – Or at link:

<https://www.atachmounts.com/assets/images/PDF%20-%20Instructions/50172%20-%20Instructions.pdf>



(1) Clean the area where the mount will attach. The bottom edge of the mount will attach into the seam between the radio and the frame around the radio illustrated with the arrow in the photo.



(2) The top edge of the mount will attach into the seam between the frame around the radio and the padded dash top illustrated with the arrow in the photo.

See additional instructions on the back side.

NOTICE: PLEASE READ THIS INFORMATION

Once the mount is screwed into or the pre-drilled holes enlarged in any way, the mount is considered used and is not refundable.

Ensure the fit of the mount onto the vehicle first. For best results, attach the mount or hold the mount over the place where the mount attaches to the dash **BEFORE** attaching the device holder to the vehicle mount to ensure a proper fit with the location. Most often the mount will appear to be a little too big or small for the intended location. Once attached, the mount should remain attached until you would like to permanently remove it.

WARNING: PROTECT from extreme heat conditions.
Extreme heat can damage the device and the mount.

Extreme temperatures can have a big impact on dash panels, cell phones, cell phone mounts and almost anything placed in the vehicle. A car windshield can also have a magnifying effect when it comes to heat on a dash, so we like to remind customers with a warning to avoid this happening when possible. A sun reflector in the windshield or park in the shade are a couple ideas that will help with extreme heat concerns.

Additional Instructions



(3) Remove the covering from the tape. Hook the thin lower (Shorter) edge of the mount into the seam illustrated in photo one. Use the seam tool to help with opening the seam if needed.



(4) press forward on the top of the mount to flex the thin top edge into the seam illustrated in photo two above. Use the seam tool to help with opening the seam if needed.

The tape will not leave any residue if the mount is removed in the future.

A-Tach Mounts Returns and Warranty link:

https://www.atachmounts.com/Warranty>Returns_ep_42-1.html

There is also a link at the bottom of every page on our website.

If you have questions, contact A-Tach Mounts cs@atachmounts.com / ATachMounts.com