

A-Tach # 50727

ST-1

A-Tach
Mounts



Designed for: Isuzu N-Series 2025 - 20__

NOTICE: The product has been tested to fit securely to the listed vehicles. Instructions are provided for your convenience. You are responsible for the use of the product and determine if you have the skill to attach the product without causing damage to your vehicle or the product. A-Tach Mounts will not be responsible for any damage to the vehicle due to the installation and/or use of the product. Read all the instructions and view the photos before attaching this product.

Online instruction can be found on the product page – Or at link:

<https://www.atachmounts.com/assets/images/PDF%20-%20Instructions/50727%20-%20Instructions.pdf>



(1) Clean the area where the mount will be attached. The lower edge of the mount will attach into the seam behind the top frame of the cubby box in the center dash illustrated with the arrow in the photo above.



(2) The upper edge of the mount will attach into the seam behind the dash bump/panel edge illustrated with the arrow in the photo above.

See additional instructions on the back side.

NOTICE: PLEASE READ THIS INFORMATION

Attach the mount first or **BEFORE** attaching the device holder to the vehicle mount to ensure there is a secure and proper fit onto the vehicle and to your satisfaction. **Once the mount is screwed into or the pre-drilled holes enlarged in any way, the mount is considered used and is not refundable.** Most often the mount will appear to be a little too big or small for the intended location. It is designed this way and will not break when flexing into place.

WARNING: PROTECT from extreme heat conditions.
Extreme heat can damage the device and the mount.

Extreme temperatures can have a big impact on dash panels, cell phones, cell phone mounts and almost anything placed in the vehicle. A car windshield can also have a magnifying effect when it comes to heat on a dash, so we like to remind customers with a warning to avoid this happening when possible. A sun reflector in the windshield or park in the shade are a couple ideas that will help with extreme heat concerns.

Additional Instructions



(3) Remove the covering from the tape. Use the seam tool if needed to open the lower seam a little. Press the lower edge of the mount into the bottom seam.



(4) Flex the top edge of the mount up and hook it into the top seam and onto the top panel.

Our mounts have been tested to fit a specific make, model, and year of vehicle. The mounts are made using patterns and templates so they should all be the same size and fit the same. Even so, A-Tach cannot guarantee a secure fit without question. This is because there are too many unseen and uncontrollable things within a dash seam and panel that can affect how a mount attaches onto the dash. Dash panels are very cosmetic in nature, and the underside or unseen edges are not always as precisely made. At times there might be something happening behind or within the seam. The panels might be too tight and block a mount from attaching. At times the dash panel clips can be too loose to hold a panel in place while the mount is attached. It does not mean there is anything wrong with the vehicle's dash or the mount. It just means that there is some reason the mount will not stay attached.

Because of the unknown possibilities, attach the mount to the dash BEFORE attaching a device holder to the vehicle mount. **DO NOT attach a device holder onto the mount until you know for certain the mount has a secure fit on your vehicle, and you are satisfied with how the mount fits your dash.**

Once the mount is screwed into or the pre-drilled holes enlarged in any way, the mount is considered used and will not be refunded if returned.

A-Tach Mounts Returns and Warranty link:

https://www.atachmounts.com/Warranty>Returns_ep_42-1.html

There is also a link at the bottom of every page on our website.

If you have questions, contact A-Tach Mounts cs@atachmounts.com / ATachMounts.com