

A-Tach # 50754

ST-1

A-Tach
Mounts



Designed for: Mini Clubman 2016 - 2018

NOTICE: The product has been tested to fit securely to the listed vehicles. Instructions are provided for your convenience. You are responsible for the use of the product and determine if you have the skill to attach the product without causing damage to your vehicle or the product. A-Tach Mounts will not be responsible for any damage to the vehicle due to the installation and/or use of the product.

Read all the instructions and view the photos before attaching this product.

Online instruction can be found on the product page – Or at link:

<https://www.atachmounts.com/assets/images/PDF%20-%20Instructions/50754%20-%20Instructions.pdf>



(1) Clean the area where the mount will be attached. The lower edge of the mount will attach into the opening above the hazard button illustrated with the arrow in the photo above.



(2) The upper edge of the mount will attach onto the edge of the dash panel in seam illustrated with the arrow in the photo above.

See additional instructions on the back side.

NOTICE: PLEASE READ THIS INFORMATION

Once the mount is screwed into or the pre-drilled holes enlarged in any way, the mount is considered used and is not refundable.

Ensure the fit of the mount onto the vehicle first. For best results, attach the mount or hold the mount over the place where the mount attaches to the dash **BEFORE** attaching the device holder to the vehicle mount to ensure a proper fit with the location. Most often the mount will appear to be a little too big or small for the intended location. Once attached, the mount should remain attached until you would like to permanently remove it.

WARNING: PROTECT from extreme heat conditions.
Extreme heat can damage the device and the mount.

Extreme temperatures can have a big impact on dash panels, cell phones, cell phone mounts and almost anything placed in the vehicle. A car windshield can also have a magnifying effect when it comes to heat on a dash, so we like to remind customers with a warning to avoid this happening when possible. A sun reflector in the windshield or park in the shade are a couple ideas that will help with extreme heat concerns.

Additional Instructions



(3) Remove the covering from the tape. Use the seam tool if needed to open the top seam a little. Press the lower edge of the mount into the opening above the hazard button.



(4) Press the mount forward until the tab connects with the display frame. The tape will not leave any residue if the mount is removed in the future.



(5) Press the top notched edge of the mount into the top seam until the notched edge hooks onto the hard plastic dash panel.



(6) The mount attached.

A-Tach Mounts Returns and Warranty link:

https://www.atachmounts.com/Warranty>Returns_ep_42-1.html

If you have questions, contact A-Tach Mounts cs@atachmounts.com / ATachMounts.com