

**A-Tach # 50755**



**Designed for:**

**A-Tach**

*Mounts*

**NOTICE:** The product has been tested to fit securely to the listed vehicles. Instructions are provided for your convenience. You are responsible for the use of the product and determine if you have the skill to attach the product without causing damage to your vehicle or the product. A-Tach Mounts will not be responsible for any damage to the vehicle due to the installation and/or use of the product.

Read all the instructions and view the photos before attaching this product.

**Online instruction can be found on the product page – Or at link:**

<https://www.atachmounts.com/assets/images/PDF%20-%20Instructions/50755%20-%20Instructions.pdf>



(1) Clean the area where the mount will be attached. The left and right edges of the mount will attach onto the left and right sides of the display illustrated with the arrow in the photo.



(2) Remove the covering from the tape. Gently feed the mount through the back side of the display. The mount will fit through.

**See additional instructions on the back side.**

## **NOTICE: PLEASE READ THIS INFORMATION**

**Once the mount is screwed into or the pre-drilled holes enlarged in any way, the mount is considered used and is not refundable.**

Ensure the fit of the mount onto the vehicle first. For best results, attach the mount or hold the mount over the place where the mount attaches to the dash **BEFORE** attaching the device holder to the vehicle mount to ensure a proper fit with the location. Most often the mount will appear to be a little too big or small for the intended location. Once attached, the mount should remain attached until you would like to permanently remove it.

**WARNING: PROTECT from extreme heat conditions.**  
**Extreme heat can damage the device and the mount.**

Extreme temperatures can have a big impact on dash panels, cell phones, cell phone mounts and almost anything placed in the vehicle. A car windshield can also have a magnifying effect when it comes to heat on a dash, so we like to remind customers with a warning to avoid this happening when possible. A sun reflector in the windshield or park in the shade are a couple ideas that will help with extreme heat concerns.

## Additional Instructions



(3) Hook the right side of the mount onto the right side of the display. Press the tape onto the side of the display. The tape will not leave any residue if the mount is removed in the future.



(4) Flex the left side of the mount out and hook the right edge over the left side of the display. Firmly press the mount onto the display side.



(5) The Mount attached.



(6) The mount will attach onto the left side of the display. However, a large phone or the steering wheel all the way in might create trouble with the phone hitting the wiper controls.

### **A-Tach Mounts Returns and Warranty link:**

[https://www.atachmounts.com/Warranty>Returns\\_ep\\_42-1.html](https://www.atachmounts.com/Warranty>Returns_ep_42-1.html)

There is also a link at the bottom of every page on our website.

If you have questions, contact A-Tach Mounts [cs@atachmounts.com](mailto:cs@atachmounts.com) / ATachMounts.com