

## A-Tach # 50764

ST-1

**A-Tach**  
Mounts



### Designed for:

Mercedes EQE 2022 - 20\_\_ & EQS 2023 - 20\_\_

**NOTICE:** The product has been tested to fit securely to the listed vehicles. Instructions are provided for your convenience. You are responsible for the use of the product and determine if you have the skill to attach the product without causing damage to your vehicle or the product. A-Tach Mounts will not be responsible for any damage to the vehicle due to the installation and/or use of the product.

Read all the instructions and view the photos before attaching this product.

**Online instruction can be found on the product page – Or at link:**

<https://www.atachmounts.com/assets/images/PDF%20-%20Instructions/50764%20-%20Instructions.pdf>



(1) Clean the area where the mount will be attached. The upper edge of the mount will attach onto the top of the center console side panel illustrated with the arrow in the photo above.



(2) The lower edge of the mount will attach into the seam between the hard console top panel and the padded lower panel illustrated with the arrow in the photo above.

**See additional instructions on the back side.**

## **NOTICE: PLEASE READ THIS INFORMATION**

Attach the mount first or **BEFORE** attaching the device holder to the vehicle mount to ensure there is a secure and proper fit onto the vehicle and to your satisfaction. **Once the mount is screwed into or the pre-drilled holes enlarged in any way, the mount is considered used and is not refundable.** Most often the mount will appear to be a little too big or small for the intended location. Once attached, the mount should remain attached until you would like to permanently remove it.

**WARNING: PROTECT from extreme heat conditions.**  
**Extreme heat can damage the device and the mount.**

Extreme temperatures can have a big impact on dash panels, cell phones, cell phone mounts and almost anything placed in the vehicle. A car windshield can also have a magnifying effect when it comes to heat on a dash, so we like to remind customers with a warning to avoid this happening when possible. A sun reflector in the windshield or park in the shade are a couple ideas that will help with extreme heat concerns.

## Additional Instructions



(3) Remove the covering from the tape. Use the seam tool if needed to open the lower seam a little. Press the left edge of the mount onto the top of the center console.



(4) Flex the lower edge of the mount out and downward to align the lower edge of the mount with the lower seam under the edge of the center console side panel.



(5) Using two hands will probably be needed.



(6) Press the lower edge of the mount all the way into the lower seam so the tape touches the console side panel. The tape will not leave any residue if the mount is removed in the future.

### **A-Tach Mounts Returns and Warranty link:**

[https://www.atachmounts.com/Warranty>Returns\\_ep\\_42-1.html](https://www.atachmounts.com/Warranty>Returns_ep_42-1.html)

There is also a link at the bottom of every page on our website.

If you have questions, contact A-Tach Mounts [cs@atachmounts.com](mailto:cs@atachmounts.com) / ATachMounts.com