

A-Tach # 10801



A-Tach **Standard** Magnetic Holder.

4 - #6 X 3/8 inch
Black Pan Head
screws are
included.


A-Tach
Mobile Device Mounts

A-Tach solutions consist of two separated parts that are brought together to create a secure mounting solution. The first part is the vehicle mount and the second part is the device holder.

Attention: Read all instructions and review the images before attaching this product.

This holder is designed for a tablet or a device in a rugged or silicone case. It is **NOT** recommended for a standard size device without a case or for a device with a thin hard case.

The holder can be used with smartphones, tablets and other devices with a solid state drive or flash memory. Older iPods and other devices with a conventional hard drive should **NOT** be used with the holder due to the magnet's possibility to damage these devices. The holder includes a disc for the back of the device or thin hard case. Due to the disc, the holder **cannot be used with wireless charging** systems or a device in a silicone case. **WARNING:** Please hold the vehicle mount and device holder over the place where the solution attaches to the dash **BEFORE** attaching the device holder to the vehicle mount to ensure a proper fit with the location of the solution. **Once screwed together the products are non-refundable. Remember:** Instructions are provided for your convenience. You are responsible to determine if you have the skill to attach the solution to your vehicle.



(1) Illustration photo only.

- Remove the ball base from the holder by loosening the ring.
- Then align the ball base of the holder with the suggested holes in the A-Tach vehicle mount.
- Attach the holder base using the included screws.
- **Remember to press in on the screws while turning them into the plastic mount.**

CAUTION: Do not over tighten the screws.

The steel screws are self-threading and will create their own threads while turning into the plastic mount.



(2) Place the tightening ring over the ball on the holder base and then attach the magnetic holder body onto the ball.

Lock the magnetic holder in place by tightening the tightening ring.

A-Tach

Mobile Device Mounts

Below are some helpful illustrations regarding the "How To" when it comes to placing the metal disc onto your device and the proper way to remove a device from an **A-Tach** Magnetic Device Holder.

For a device without a case or a device in a hard case.



(1) Peel off the cover on the back of the disc.



(2) Place the disc onto the center of the back of the device or hard case.

How to properly remove your device from your **A-Tach** Magnetic Device Holder.



(1) **DO NOT** pull the device straight off the holder. The pull will be much stronger.



(2) Instead, tilt the device to the right or left first. This will release the device from the holder more gradually and the pull will be easier to release.