

A-Tach # 50167



Designed for: Honda Pilot 2009 - 2015

A-Tach

Mounts

NOTICE: A-Tach Mounts will not be responsible for any damage to the vehicle due to the installation and/or use of the product. The product has been tested to fit securely to the listed vehicles. Instructions are provided for your convenience. You are responsible for the use of the product and to determine if you have the skill to attach the product without causing damage to your vehicle or the product.

Read all instructions and view the photos before attaching this product.

NOTICE: Please hold the vehicle mount and device holder over the place where the solution attaches to the dash **BEFORE** attaching the device holder to the vehicle mount to ensure a proper fit with the location of the solution. **Once screwed together the products are non-refundable.**

Remember: Instructions are provided for your convenience. You are responsible to determine if you have the skill to attach the solution to your vehicle.

WARNING: DO NOT interact with the device while the vehicle is in motion.



(1) Clean the area where the mount will attach. The mount will attach into the seam right in the center of the "T" seam intersect illustrated with the arrows in the photo.



(2) the forward edge of the mount will go into the seam between the side frame around the display and the display or display frame depending on the dash styling you have. See arrow above.



(3) Remove the covering from the tape. Press the large tab on the left edge of the mount all the way into the "T" seam intersect illustrated in photo one.



(4) Press forward on the right side of the mount until the front edge hooks behind the display side panel illustrated in photo 2. The tape will not leave any residue if the mount is removed in the future.

Warranty and Returns

A-Tach Mounts Limited Warranty

A-Tach warrants the product to be free of all defects in materials and workmanship for a period of six (6) months from the date of purchase. This warranty extends to the original buyer. Damaged products caused by anything outside of shipping damage are not covered by this warranty.

Within the period of this warranty, A-Tach has the option to repair or replace the item or refund the purchase price. Any replacement parts will be done on an exchange basis. All repairs and service must be done by A-Tach. Product must be delivered to A-Tach during the warranty time along with proof of purchase price and date. The shipping and packaging costs will be the buyer's responsibility. Labor costs and parts to repair will be A-Tach Mounts responsibility.

A-Tach Mounts will not be responsible for any damage to the vehicle or product due to the installation and/or use of the product. A-Tach is not responsible for damages caused by extreme heat conditions. Any above exclusion may not apply in states that do not allow the exclusion or limitation. This warranty gives you specific legal rights. You also may have other rights which vary from state to state.

Returns

Before any product may be returned, A-Tach must give prior approval. An RMA# (Return Merchandise Authorization Number) needs to be given to the buyer to return a product. All returns must be within (30) days of the invoice date and include proof of purchase. Any returned product must be undamaged and in like new condition. Returned product must be scratch free with no additional holes or screw marks on the product.

A-Tach reserves the right to withhold any refund if the product is believed to be damaged. A return must include a copy of the original order or invoice. All parts and components that were shipped with the original product must be included with the returned product.

Contact Information:

A-Tach Mounts
Clarkston, WA 99403
cs@atachmounts.com