

A-Tach # 10101



A-Tach Universal Holder – Elegant Style

4 - #6 X 3/8 inch
Black Pan Head
screws are included.

A-Tach

Mobile Device Mounts

A-Tach solutions consist of two separated parts that are brought together to create a secure mounting solution. The first part is the vehicle mount and the second part is the device holder.

Attention: Read all instructions and review the images before attaching this product.

The holder will fit devices with these dimensions:
Minimum width 50 mm or 1 15/16 inches
Maximum width 90 mm cm or 3 5/8 inches
Maximum thickness 12 mm or 1/2 inches
Fits 4-6 inch mobile phone screens.

** Remember to consider the case when measuring.

NOTICE: Before you attach the device holder onto the vehicle mount, attach the vehicle mount onto the vehicle to ensure a proper fit.

Instructions are provided for your convenience. You are responsible to determine if you have the skill to attach the solution to your vehicle.



(1) Illustration photo only.

- Remove the ball base from the holder by loosening the ring.
- Then **the ball base should be attached to the vehicle.**
- Align the ball base of the holder with the suggested holes in the A-Tach vehicle mount.
- Attach the holder base using the included screws.
- Remember to press in on the screws while turning them into the plastic mount.

CAUTION: Do not over tighten the screws.

The steel screws are self-threading and will create their own threads while turning into the plastic mount.



(2) Once the ball base is on the mount,

- Place the ring all the way over the ball on the base.
- Then take the holder and press the socket on the back of the holder onto the ball on the base.
- Press the ball all the way into the socket.
- Then tighten the ring back onto the threads on the socket.
- Adjust the holder to the desired position and tighten the ring to desired tightness.

See additional instructions on the back side.

One-Button Start

Automatically Open The Back-Clip



(3) Press the button on the back to open the holder to place a device into the holder.

Can be operated with one hand.

Great for navigation and answering the phone.



(4) Place the device into the holder and tighten by pressing in on the sides.

Warranty and Returns

A-Tach Mounts Limited Warranty

A-Tach warrants the product to be free of all defects in materials and workmanship for a period of six (6) months from the date of purchase. This warranty extends to the original buyer. Damaged products caused by anything outside of shipping damage are not covered by this warranty.

Within the period of this warranty, A-Tach has the option to repair or replace the item or refund the purchase price. Any replacement parts will be done on an exchange basis. All repairs and service must be done by A-Tach. Product must be delivered to A-Tach during the warranty time along with proof of purchase price and date. A-Tach mounts does not supply return shipping labels. The shipping and packaging costs will be the buyer's responsibility. Labor costs and parts to repair will be A-Tach Mounts responsibility.

A-Tach Mounts will not be responsible for any damage to the vehicle or product due to the installation and/or use of the product. A-Tach is not responsible for damage caused by extreme heat conditions. Any above exclusion may not apply in states that do not allow the exclusion or limitation. This warranty gives you specific legal rights. You also may have other rights which vary from state to state.

Returns

Before any product may be returned, A-Tach must give prior approval. An RMA# (Return Merchandise Authorization Number) needs to be given to the buyer to return a product. All returns must be within (30) days of the invoice date and include proof of purchase. Any returned product must be undamaged and in like new condition. Returned product must be scratch free with no additional holes or screw marks on the product. A-Tach mounts does not supply return shipping labels. The shipping and packaging costs will be the buyer's responsibility.

A-Tach reserves the right to withhold any refund if the product is believed to be damaged. A return must include a copy of the original order or invoice. All parts and components that were shipped with the original product must be included with the returned product.

Contact Information:

A-Tach Mounts
Clarkston, WA 99403
cs@attachmounts.com